

List of Suggested Mobile Handsets

Vendors	Model No.
Alcatel	Alcatel/One Touch 735i
Alcatel	Alcatel/One Touch 756
BenQ	BenQ/P30
BlackBerry	BlackBerry/4.0
BlackBerry	BlackBerry/4.1
BlackBerry	BlackBerry/4.2
BlackBerry	BlackBerry/4.2TrackBall
BlackBerry	BlackBerry/4.3
BlackBerry	BlackBerry/4.5
BlackBerry	BlackBerry/4.6
BlackBerry	BlackBerry/4.7
BlackBerry	BlackBerry/8130
BlackBerry	BlackBerry/8120
BlackBerry	BlackBerry/8700
BlackBerry	BlackBerry/8707
BlackBerry	BlackBerry/8800
BlackBerry	BlackBerry/8830
BlackBerry	BlackBerry/Curve
BlackBerry	BlackBerry/8300
BlackBerry	BlackBerry/Pearl
BlackBerry	BlackBerry/8100
BlackBerry	BlackBerry/5810
BlackBerry	BlackBerry/7290
BlackBerry	BlackBerry/7100t
BlackBerry	BlackBerry/7130g
BlackBerry	BlackBerry/7520
BlackBerry	BlackBerry/5820

Casio	Casio/C452CA
DoJa	DoJa/os15
DoJa	DoJa/os25
Hitachi	Hitachi/C3001H
HTC	HTC/Himalaya
HTC	HTC/Hermes
HTC	HTC/TyTN
HTC	HTC/Tornado
HTC	HTC/Wizard
HTC	HTC/Titan
HTC	HTC/Excalibur
HTC	HTC/S620
HTC	HTC/S621
HTC	HTC/Vox
HTC	HTC/S720
Imate	Imate/JasJar
Imate	Imate/K-Jam
Imate	Imate/Jam
Imate	Imate/Jamin
Imate	Imate/SP3
Imate	Imate/SP3K
Imate	Imate/SP5
Kyocera	Kyocera/C3002K
Kyocera	Kyocera/Cyclops
LG Electronics	LG/CU500
LG Electronics	LG/CU500v
LG Electronics	LG/TU500
LG Electronics	LG/CU400
LG Electronics	LG/KG800

LG Electronics	LG/C-nain 2000
LG Electronics	LG/LX5350
LG Electronics	LG/U8138
LG Electronics	LG/Shiny
LG Electronics	LG/KE970
Mio	Mio/8390
Mitsubishi	Mitsubishi/J-D05
Motorola	Motorola/Motorokr_Z6
Motorola	Motorola/Z6
Motorola	Motorola/Motoslvr_L7i
Motorola	Motorola/L7i
Motorola	Motorola/Motoslvr_L7e
Motorola	Motorola/L7e
Motorola	Motorola/MotoRazr2V8
Motorola	Motorola/Razr2V8
Motorola	Motorola/A1200
Motorola	Motorola/Ming
Motorola	Motorola/E1070
Motorola	Motorola/PEBL-U6
Motorola	Motorola/Q
Motorola	Motorola/Q9
Motorola	Motorola/I870
Motorola	Motorola/E770
Motorola	Motorola/C975
Motorola	Motorola/FOMA_M1000
Motorola	Motorola/SLVR
Motorola	Motorola/C261
Motorola	Motorola/V1050
Motorola	Motorola/V8

Motorola	Motorola/V1100
Motorola	Motorola/V195
Motorola	Motorola/V197
Motorola	Motorola/V360
Motorola	Motorola/V635
Motorola	Motorola/MPx200
Motorola	Motorola/V980
Motorola	Motorola/V550
Motorola	Motorola/V551
Motorola	Motorola/V620
Motorola	Motorola/A780
Motorola	Motorola/A760
Motorola	Motorola/i730
Motorola	Motorola/i50sx
Motorola	Motorola/i55sr
Motorola	Motorola/i85s
Motorola	Motorola/i80s
Motorola	Motorola/i88s
Motorola	Motorola/i90c
Motorola	Motorola/i95cl
Motorola	Motorola/C650
Motorola	Motorola/E680
Motorola	Motorola/C380
Motorola	Motorola/E398
Motorola	Motorola/E398Emulator
Motorola	Motorola/Motorokr_E6
Motorola	Motorola/E6
Motorola	Motorola/Motorizr_Z3
Motorola	Motorola/Z3

Motorola	Motorola/Motorazr_Z8
Motorola	Motorola/Motorazr_V3xx
Motorola	Motorola/V3xx
Motorola	Motorola/Motorazr_V3t
Motorola	Motorola/V3t
Motorola	Motorola/Motorazr_V3x
Motorola	Motorola/V3x
Motorola	Motorola/Motorazr_V3i
Motorola	Motorola/V3i
Motorola	Motorola/Motorazr_V3e
Motorola	Motorola/V3e
Motorola	Motorola/V3
Motorola	Motorola/Motorazr_V3-CLDC1.1
Motorola	Motorola/V3-CLDC1.1
Motorola	Motorola/Motorazr-maxx-V6
Motorola	Motorola/V6
Motorola	Motorola/Motokr_zr_K1
Motorola	Motorola/K1
Motorola	Motorola/Motorokr_E1
Motorola	Motorola/E1
Motorola	Motorola/Motorokr_E2
Motorola	Motorola/E2
Motorola	Motorola/L2
Motorola	Motorola/L6
Motorola	Motorola/L6i
Motorola	Motorola/Motoslvr_L7
Motorola	Motorola/L7
Motorola	Motorola/V3-CLDC1.0
Motorola	Motorola/A920

Motorola	Motorola/A925
Motorola	Motorola/A1000
Motorola	Motorola/E1000
Motorola	Motorola/A630
Motorola	Motorola/E680i
Motorola	Motorola/A728
Motorola	Motorola/A845
Motorola	Motorola/A910
Motorola	Motorola/C980
Motorola	Motorola/V180
Motorola	Motorola/V220
Motorola	Motorola/V80
Motorola	Motorola/C370
Motorola	Motorola/C450
Motorola	Motorola/C550
Motorola	Motorola/E380
Motorola	Motorola/T725
Motorola	Motorola/V300
Motorola	Motorola/V303
Motorola	Motorola/V365
Motorola	Motorola/V400
Motorola	Motorola/V500
Motorola	Motorola/V525
Motorola	Motorola/V600
Motorola	Motorola/A388
Motorola	Motorola/A830
Motorola	Motorola/T280i
Motorola	Motorola/T720(GSM)
Motorola	Motorola/T720(CDMA)

Motorola	Motorola/T720i
Motorola	Motorola/E550
Motorola	Motorola/E815
Motorola	Motorola/E816
Motorola	Motorola/i256
Motorola	Motorola/i275
Motorola	Motorola/i285
Motorola	Motorola/i325
Motorola	Motorola/i325is
Motorola	Motorola/i355
Motorola	Motorola/i415
Motorola	Motorola/i450
Motorola	Motorola/i560
Motorola	Motorola/i580
Motorola	Motorola/i605
Motorola	Motorola/i615
Motorola	Motorola/i670
Motorola	Motorola/i710
Motorola	Motorola/i760
Motorola	Motorola/i830
Motorola	Motorola/i833
Motorola	Motorola/i850
Motorola	Motorola/i855
Motorola	Motorola/i860
Motorola	Motorola/i875
Motorola	Motorola/i930
Motorola	Motorola/ic402
Motorola	Motorola/ic502
Motorola	Motorola/ic602

Motorola	Motorola/ic902
Motorola	Motorola/M710
Motorola	Motorola/Q8
Motorola	Motorola/Q9c
Motorola	Motorola/Q9h
Motorola	Motorola/Q9m
Motorola	Motorola/Z8
Motorola	Motorola/MaxxVe
Motorola	Motorola/V3c
Motorola	Motorola/Motorazr2v8
Motorola	Motorola/Motorazr2v9
Motorola	Motorola/MotorokrU9
Motorola	Motorola/MotorokrZ6
Motorola	Motorola/MotorokrZ6m
Motorola	Motorola/Motoslvr L7i
Motorola	Motorola/Motoslvr L7e
Motorola	Motorola/Motoslvr L9
Motorola	Motorola/V325
Motorola	Motorola/V710
Motorola	Motorola/V975
Motorola	Motorola/W210
Motorola	Motorola/W315
Motorola	Motorola/W355
Motorola	Motorola/W385
Motorola	Motorola/W490
Motorola	Motorola/W510
Native	Native/iPhone
Native	Native/WindowsMobile
NEC	NEC/E616

Nokia	Nokia/3600slide
Nokia	Nokia/3120classic
Nokia	Nokia/3120c
Nokia	Nokia/5610
Nokia	Nokia/E66
Nokia	Nokia/E71
Nokia	Nokia/N78
Nokia	Nokia/6660
Nokia	Nokia/5070
Nokia	Nokia/7360
Nokia	Nokia/7370
Nokia	Nokia/6103
Nokia	Nokia/6125
Nokia	Nokia/6165
Nokia	Nokia/6234
Nokia	Nokia/6233
Nokia	Nokia/2855
Nokia	Nokia/Series40
Nokia	Nokia/Series40DP1
Nokia	Nokia/Series60
Nokia	Nokia/Series60E1
Nokia	Nokia/Series90
Nokia	Nokia/Midp2Cldc11
Nokia	Nokia/Series40DP3
Nokia	Nokia/Series40E3
Nokia	Nokia/Series40Midp2
Nokia	Nokia/Series60Midp2
Nokia	Nokia/Series60E2
Nokia	Nokia/Series60E2FP1

Nokia	Nokia/Series60E2FP2
Nokia	Nokia/Series60E2FP3
Nokia	Nokia/Series60E3
Nokia	Nokia/Series40DP2
Nokia	Nokia/2355
Nokia	Nokia/5500
Nokia	Nokia/E50
Nokia	Nokia/5140i
Nokia	Nokia/6280
Nokia	Nokia/6265
Nokia	Nokia/6265i
Nokia	Nokia/6111
Nokia	Nokia/6270
Nokia	Nokia/6060
Nokia	Nokia/6290
Nokia	Nokia/6110
Nokia	Nokia/6110_Navigator
Nokia	Nokia/6210
Nokia	Nokia/6210_Navigator
Nokia	Nokia/N3250
Nokia	Nokia/E62
Nokia	Nokia/E65
Nokia	Nokia/E61i
Nokia	Nokia/E61
Nokia	Nokia/E60
Nokia	Nokia/E70
Nokia	Nokia/E90
Nokia	Nokia/E90_Communicator
Nokia	Nokia/N76

Nokia	Nokia/N75
Nokia	Nokia/N95
Nokia	Nokia/5700
Nokia	Nokia/6120
Nokia	Nokia/6120_classic
Nokia	Nokia/N93
Nokia	Nokia/N93i
Nokia	Nokia/N92
Nokia	Nokia/N91
Nokia	Nokia/N90
Nokia	Nokia/N70
Nokia	Nokia/N71
Nokia	Nokia/N72
Nokia	Nokia/N73
Nokia	Nokia/N77
Nokia	Nokia/N80
Nokia	Nokia/2626
Nokia	Nokia/6085
Nokia	Nokia/6288
Nokia	Nokia/5300
Nokia	Nokia/5200
Nokia	Nokia/6133
Nokia	Nokia/6300
Nokia	Nokia/6086
Nokia	Nokia/6070
Nokia	Nokia/6131
Nokia	Nokia/6131_NFC
Nokia	Nokia/6080
Nokia	Nokia/6151

Nokia	Nokia/6126
Nokia	Nokia/2610
Nokia	Nokia/2865
Nokia	Nokia/2865i
Nokia	Nokia/6136
Nokia	Nokia/6275
Nokia	Nokia/6275i
Nokia	Nokia/7390
Nokia	Nokia/8800_Sirocco_Edition
Nokia	Nokia/8800
Nokia	Nokia/8801
Nokia	Nokia/3152
Nokia	Nokia/3155
Nokia	Nokia/3155i
Nokia	Nokia/6152
Nokia	Nokia/6155
Nokia	Nokia/6155i
Nokia	Nokia/6030
Nokia	Nokia/6021
Nokia	Nokia/6230i
Nokia	Nokia/6682
Nokia	Nokia/6101
Nokia	Nokia/6282
Nokia	Nokia/6102i
Nokia	Nokia/6102
Nokia	Nokia/6680
Nokia	Nokia/6681
Nokia	Nokia/6822
Nokia	Nokia/6235

Nokia	Nokia/6235i
Nokia	Nokia/7710
Nokia	Nokia/6020
Nokia	Nokia/3230
Nokia	Nokia/6670
Nokia	Nokia/7270
Nokia	Nokia/7260
Nokia	Nokia/9300i
Nokia	Nokia/9300
Nokia	Nokia/3587
Nokia	Nokia/6651
Nokia	Nokia/6170
Nokia	Nokia/6260
Nokia	Nokia/6630
Nokia	Nokia/N-Gage_QD
Nokia	Nokia/7610
Nokia	Nokia/6620
Nokia	Nokia/3660
Nokia	Nokia/3620
Nokia	Nokia/6600
Nokia	Nokia/3600
Nokia	Nokia/N-Gage
Nokia	Nokia/3650
Nokia	Nokia/7650
Nokia	Nokia/6255
Nokia	Nokia/9500
Nokia	Nokia/5140
Nokia	Nokia/7700
Nokia	Nokia/6230

Nokia	Nokia/3220
Nokia	Nokia/6610i
Nokia	Nokia/6310i
Nokia	Nokia/3120
Nokia	Nokia/3108
Nokia	Nokia/6010
Nokia	Nokia/6810
Nokia	Nokia/7200
Nokia	Nokia/6820
Nokia	Nokia/7600
Nokia	Nokia/3200
Nokia	Nokia/3100
Nokia	Nokia/6108
Nokia	Nokia/6560
Nokia	Nokia/3560
Nokia	Nokia/3520
Nokia	Nokia/3410
Nokia	Nokia/3590
Nokia	Nokia/7250i
Nokia	Nokia/3300
Nokia	Nokia/6220
Nokia	Nokia/3595
Nokia	Nokia/6800
Nokia	Nokia/6200
Nokia	Nokia/6100
Nokia	Nokia/8910i
Nokia	Nokia/7250
Nokia	Nokia/5100
Nokia	Nokia/6650

Nokia	Nokia/3530
Nokia	Nokia/3510i
Nokia	Nokia/6610
Nokia	Nokia/7210
Nokia	Nokia/N95_8GB
Nokia	Nokia/N91_8GB
Nokia	Nokia/N82
Nokia	Nokia/N81
Nokia	Nokia/N81_8GB
Nokia	Nokia/E51
Nokia	Nokia/5310_XpressMusic
Nokia	Nokia/5610_XpressMusic
Nokia	Nokia/5700_XpressMusic
Nokia	Nokia/6500_classic
Nokia	Nokia/6500_slide
Nokia	Nokia/6555
Nokia	Nokia/6585
O2	O2/XDAII
Palm	Palm/Treo700p
Palm	Palm/Treo700w
Palm	Palm/Treo700wx
Palm	Palm/Treo750
Palm	Palm/Treo680
Palm	Palm/Treo650
Palm	Palm/Treo755p
Palm	Palm/TungstenC
Palm	Palm/TungstenE2
Panasonic	Panasonic/C3003P
Panasonic	Panasonic/X60

Qtek	Qtek/8310
Qtek	Qtek/9100
Qtek	Qtek/XDAII
Sagem	Sagem/MyX5-2
Sagem	Sagem/MyX6
Sagem	Sagem/MyX6-2
Sagem	Sagem/MyX7
Sagem	Sagem/My700x
Sagem	Sagem/MyW-7
Sagem	Sagem/MyC5-2
Sagem	Sagem/MyZ-5
Sagem	Sagem/My400x
Sagem	Sagem/My300x
Sagem	Sagem/MyC4
Sagem	Sagem/MyX-8
Sagem	Sagem/MyX-4
Sagem	Sagem/MyV-75
Sagem	Sagem/MyV-65
Sagem	Sagem/MyV-55
Samsung	Samsung/SGH-F700
Samsung	Samsung/SGH-Z500
Samsung	Samsung/SGH-U700
Samsung	Samsung/SGH-U600
Samsung	Samsung/Blackjack
Samsung	Samsung/SGH-E250
Samsung	Samsung/SGH-X830
Samsung	Samsung/SGH-E810
Samsung	Samsung/SGH-E898
Samsung	Samsung/SGH-E870

Samsung	Samsung/SPH-A900
Samsung	Samsung/SGH-E900
Samsung	Samsung/SGH-P300
Samsung	Samsung/SGH-P310
Samsung	Samsung/SGH-P858
Samsung	Samsung/SPH-I600
Samsung	Samsung/SGH-T509
Samsung	Samsung/SGH-T619
Samsung	Samsung/SGH-T629
Samsung	Samsung/SGH-T609
Samsung	Samsung/SGH-T709
Samsung	Samsung/SGH-X700
Samsung	Samsung/SGH-X708
Samsung	Samsung/SGH-X820
Samsung	Samsung/SGH-Z400
Samsung	Samsung/SGH-Z540
Samsung	Samsung/SGH-Z720
Samsung	Samsung/SGH-Z560
Samsung	Samsung/SGH-E730
Samsung	Samsung/SGH-E760
Samsung	Samsung/SGH-E770
Samsung	Samsung/SGH-E788
Samsung	Samsung/SGH-E780
Samsung	Samsung/SGH-E570
Samsung	Samsung/SGH-E530
Samsung	Samsung/SGH-E380
Samsung	Samsung/SGH-E388
Samsung	Samsung/SGH-E390
Samsung	Samsung/SGH-E490

Samsung	Samsung/SGH-E500
Samsung	Samsung/SGH-D820
Samsung	Samsung/SGH-D828
Samsung	Samsung/SGH-D908
Samsung	Samsung/SGH-C130
Samsung	Samsung/SGH-D520
Samsung	Samsung/SGH-D608
Samsung	Samsung/SGH-T809
Samsung	Samsung/SGH-E720
Samsung	Samsung/SGH-ZM60
Samsung	Samsung/SGH-D720
Samsung	Samsung/SGH-D730
Samsung	Samsung/Z100
Samsung	Samsung/Z105
Samsung	Samsung/P730
Samsung	Samsung/P735
Samsung	Samsung/E300
Samsung	Samsung/E310
Samsung	Samsung/E370
Samsung	Samsung/E380
Samsung	Samsung/E600
Samsung	Samsung/E810
Samsung	Samsung/D410
Samsung	Samsung/D415
Samsung	Samsung/D418
Samsung	Samsung/E400
Samsung	Samsung/E418
Samsung	Samsung/E710
Samsung	Samsung/E715

Samsung	Samsung/P400
Samsung	Samsung/E105
Samsung	Samsung/X105
Samsung	Samsung/X450
Samsung	Samsung/X458
Samsung	Samsung/X430
Samsung	Samsung/X427
Samsung	Samsung/X426
Samsung	Samsung/X400
Samsung	Samsung/C100
Samsung	Samsung/C110
Samsung	Samsung/D100
Samsung	Samsung/D108
Samsung	Samsung/S300
Samsung	Samsung/S300M
Samsung	Samsung/S307
Samsung	Samsung/S200
Samsung	Samsung/S208
Samsung	Samsung/S100
Samsung	Samsung/S105
Samsung	Samsung/SGH-D500
Samsung	Samsung/SGH-D600
Samsung	Samsung/SGH-D800
Samsung	Samsung/SGH-E100
Samsung	Samsung/SGH-D900
Samsung	Samsung/E100A
Samsung	Samsung/E108
Samsung	Samsung/SGH-E330
Samsung	Samsung/SGH-E600

Samsung	Samsung/SGH-E630
Samsung	Samsung/SGH-E700
Samsung	Samsung/E700A
Samsung	Samsung/E708
Samsung	Samsung/SGH-E800
Samsung	Samsung/E800C
Samsung	Samsung/E808
Samsung	Samsung/SGH-E820
Samsung	Samsung/SGH-X100
Samsung	Samsung/X100A
Samsung	Samsung/X108
Samsung	Samsung/SGH-X600
Samsung	Samsung/X600A
Samsung	Samsung/X608
Samsung	Samsung/SGH-A700
Samsung	Samsung/SCH-X130
Samsung	Samsung/SCH-X230
Samsung	Samsung/SCH-X250
Samsung	Samsung/SCH-X350
Samsung	Samsung/SGH-S100
Samsung	Samsung/SPH-N400
Samsung	Samsung/SPH-X4209
Sanyo	Sanyo/A3011SA
Sanyo	Sanyo/SCP-4900
Sanyo	Sanyo/SCP-5300
Sendo	Sendo/X
Sharp	Sharp/J-SH07
Sharp	Sharp/J-SH08
Sharp	Sharp/GX10

Sharp	Sharp/GX10i
Sharp	Sharp/GX15
Sharp	Sharp/GX20
Sharp	Sharp/GX25
Sharp	Sharp/GX30
Sharp	Sharp/GX30i
Sharp	Sharp/TM100
Sharp	Sharp/TM200
Sharp	Sharp/902
Sharp	Sharp/SGH-902
Siemens	Siemens/x55
Siemens	Siemens/x65
Siemens	Siemens/x75
Siemens	Siemens/EF81
Siemens	Siemens/EL71
Siemens	Siemens/SXG75
Siemens	Siemens/A56i
Siemens	Siemens/C55
Siemens	Siemens/C56
Siemens	Siemens/2128
Siemens	Siemens/CT56
Siemens	Siemens/C60
Siemens	Siemens/C61
Siemens	Siemens/C65
Siemens	Siemens/CF62
Siemens	Siemens/CX65
Siemens	Siemens/M46
Siemens	Siemens/M50
Siemens	Siemens/MT50

Siemens	Siemens/3138
Siemens	Siemens/M55
Siemens	Siemens/M56
Siemens	Siemens/M65
Siemens	Siemens/S65
Siemens	Siemens/SK65
Siemens	Siemens/MC60
Siemens	Siemens/S55
Siemens	Siemens/S56
Siemens	Siemens/S57
Siemens	Siemens/SL55
Siemens	Siemens/SL56
Siemens	Siemens/SL75
Siemens	Siemens/ST60
Siemens	Siemens/SX1
Sony-Ericsson	Sony-Ericsson/JavaPlatform1
Sony-Ericsson	Sony-Ericsson/JavaPlatform2
Sony-Ericsson	Sony-Ericsson/JavaPlatform3
Sony-Ericsson	Sony-Ericsson/JavaPlatform4
Sony-Ericsson	Sony-Ericsson/JavaPlatform5
Sony-Ericsson	Sony-Ericsson/JavaPlatform6
Sony-Ericsson	Sony-Ericsson/JavaPlatform7
Sony-Ericsson	Sony-Ericsson/JavaPlatform7_176x220
Sony-Ericsson	Sony-Ericsson/JavaPlatform8
Sony-Ericsson	Sony-Ericsson/JavaPlatform8_176x220
Sony-Ericsson	Sony-Ericsson/JavaPlatform8_240x320
Sony-Ericsson	Sony-Ericsson/JavaPlatform1Symbian
Sony-Ericsson	Sony-Ericsson/JavaPlatform2Symbian
Sony-Ericsson	Sony-Ericsson/C902

Sony-Ericsson	Sony-Ericsson/C702
Sony-Ericsson	Sony-Ericsson/K320i
Sony-Ericsson	Sony-Ericsson/K320
Sony-Ericsson	Sony-Ericsson/W830i
Sony-Ericsson	Sony-Ericsson/W830
Sony-Ericsson	Sony-Ericsson/W950i
Sony-Ericsson	Sony-Ericsson/W710i
Sony-Ericsson	Sony-Ericsson/W710
Sony-Ericsson	Sony-Ericsson/Z550i
Sony-Ericsson	Sony-Ericsson/Z550
Sony-Ericsson	Sony-Ericsson/Z525
Sony-Ericsson	Sony-Ericsson/Z530
Sony-Ericsson	Sony-Ericsson/Z710
Sony-Ericsson	Sony-Ericsson/K510
Sony-Ericsson	Sony-Ericsson/Z300
Sony-Ericsson	Sony-Ericsson/Z300a
Sony-Ericsson	Sony-Ericsson/P990i
Sony-Ericsson	Sony-Ericsson/M600
Sony-Ericsson	Sony-Ericsson/K310i
Sony-Ericsson	Sony-Ericsson/K310
Sony-Ericsson	Sony-Ericsson/W810i
Sony-Ericsson	Sony-Ericsson/W810
Sony-Ericsson	Sony-Ericsson/K810i
Sony-Ericsson	Sony-Ericsson/W850i
Sony-Ericsson	Sony-Ericsson/W850
Sony-Ericsson	Sony-Ericsson/K850i
Sony-Ericsson	Sony-Ericsson/K850
Sony-Ericsson	Sony-Ericsson/K800i
Sony-Ericsson	Sony-Ericsson/K800

Sony-Ericsson	Sony-Ericsson/Mylo
Sony-Ericsson	Sony-Ericsson/W880
Sony-Ericsson	Sony-Ericsson/W880i
Sony-Ericsson	Sony-Ericsson/W900
Sony-Ericsson	Sony-Ericsson/W900i
Sony-Ericsson	Sony-Ericsson/W900_emu
Sony-Ericsson	Sony-Ericsson/W800i
Sony-Ericsson	Sony-Ericsson/W800
Sony-Ericsson	Sony-Ericsson/W800_emu
Sony-Ericsson	Sony-Ericsson/W610i
Sony-Ericsson	Sony-Ericsson/W600
Sony-Ericsson	Sony-Ericsson/W550
Sony-Ericsson	Sony-Ericsson/W580i
Sony-Ericsson	Sony-Ericsson/W580
Sony-Ericsson	Sony-Ericsson/K608
Sony-Ericsson	Sony-Ericsson/Z520
Sony-Ericsson	Sony-Ericsson/D750
Sony-Ericsson	Sony-Ericsson/Z800
Sony-Ericsson	Sony-Ericsson/V800
Sony-Ericsson	Sony-Ericsson/V802
Sony-Ericsson	Sony-Ericsson/W300
Sony-Ericsson	Sony-Ericsson/J300
Sony-Ericsson	Sony-Ericsson/K300
Sony-Ericsson	Sony-Ericsson/K790
Sony-Ericsson	Sony-Ericsson/K750
Sony-Ericsson	Sony-Ericsson/K750i
Sony-Ericsson	Sony-Ericsson/K600
Sony-Ericsson	Sony-Ericsson/V600
Sony-Ericsson	Sony-Ericsson/V630

Sony-Ericsson	Sony-Ericsson/K610i
Sony-Ericsson	Sony-Ericsson/T610
Sony-Ericsson	Sony-Ericsson/T618
Sony-Ericsson	Sony-Ericsson/T616
Sony-Ericsson	Sony-Ericsson/T628
Sony-Ericsson	Sony-Ericsson/T630
Sony-Ericsson	Sony-Ericsson/T637
Sony-Ericsson	Sony-Ericsson/Z600
Sony-Ericsson	Sony-Ericsson/Z608
Sony-Ericsson	Sony-Ericsson/Z1010
Sony-Ericsson	Sony-Ericsson/P800
Sony-Ericsson	Sony-Ericsson/P802
Sony-Ericsson	Sony-Ericsson/P900
Sony-Ericsson	Sony-Ericsson/P908
Sony-Ericsson	Sony-Ericsson/K700
Sony-Ericsson	Sony-Ericsson/K700i
Sony-Ericsson	Sony-Ericsson/K700c
Sony-Ericsson	Sony-Ericsson/K500
Sony-Ericsson	Sony-Ericsson/K500i
Sony-Ericsson	Sony-Ericsson/F500
Sony-Ericsson	Sony-Ericsson/F500i
Sony-Ericsson	Sony-Ericsson/K500c
Sony-Ericsson	Sony-Ericsson/Z500
Sony-Ericsson	Sony-Ericsson/Z500a
Sony-Ericsson	Sony-Ericsson/Z500i
Sony-Ericsson	Sony-Ericsson/S700
Sony-Ericsson	Sony-Ericsson/S700i
Sony-Ericsson	Sony-Ericsson/S700c
Sony-Ericsson	Sony-Ericsson/P910

Sony-Ericsson	Sony-Ericsson/P910i
Sony-Ericsson	Sony-Ericsson/P910c
Sony-Ericsson	Sony-Ericsson/P910a
Sony-Ericsson	Sony-Ericsson/K530
Sony-Ericsson	Sony-Ericsson/K550im
Sony-Ericsson	Sony-Ericsson/K618
Sony-Ericsson	Sony-Ericsson/K630
Sony-Ericsson	Sony-Ericsson/K660
Sony-Ericsson	Sony-Ericsson/K770
Sony-Ericsson	Sony-Ericsson/K550
Sony-Ericsson	Sony-Ericsson/P1
Sony-Ericsson	Sony-Ericsson/P1i
Sony-Ericsson	Sony-Ericsson/S500
Sony-Ericsson	Sony-Ericsson/T650
Sony-Ericsson	Sony-Ericsson/V640
Sony-Ericsson	Sony-Ericsson/W200
Sony-Ericsson	Sony-Ericsson/W350
Sony-Ericsson	Sony-Ericsson/W380
Sony-Ericsson	Sony-Ericsson/W700
Sony-Ericsson	Sony-Ericsson/W760
Sony-Ericsson	Sony-Ericsson/W910
Sony-Ericsson	Sony-Ericsson/W960
Sony-Ericsson	Sony-Ericsson/Z250
Sony-Ericsson	Sony-Ericsson/Z310
Sony-Ericsson	Sony-Ericsson/Z320
Sony-Ericsson	Sony-Ericsson/Z555
Sony-Ericsson	Sony-Ericsson/Z558
Sony-Ericsson	Sony-Ericsson/Z610
Sony-Ericsson	Sony-Ericsson/Z750

Sony-Ericsson	Sony-Ericsson/Z770
T-Mobile	T-Mobile/MDAcompact
T-Mobile	T-Mobile/MDA
T-Mobile	T-Mobile/MDAII
T-Mobile	T-Mobile/SDA
T-Mobile	T-Mobile/Dash
Toshiba	Toshiba/A3013T
Toshiba	Toshiba/C5001T
Toshiba	Toshiba/J-T06
Verizon	Verizon/XV8600
Verizon	Vertu/Constellation
Vodafone	Vodafone/Samsung-SGH-F700
Vodafone	Vodafone/Sharp-GX20
Vodafone	Vodafone/Sharp-GX10i
Vodafone	Vodafone/Sharp-GX10
Vodafone	Vodafone/Motorola-V525
Vodafone	Vodafone/Motorola-V600
Vodafone	Vodafone/Sony-Ericsson-F500i
Vodafone	Vodafone/Sony-Ericsson-V600